

**RAKIRO BIOTECH SYSTEMS PVT LTD**

R-466, TTC Industrial Area, MIDC

Rabale, Navi Mumbai - 400701

Tel No. +91-022-47804040

Email :- sales@rakiro.net

Doc No : PDAE219**Date :** 01-02-2024**Type :** AQUASOL**Product Code:** AE219**PRODUCT DATA SHEET****1 INFORMATION**

CODE: AE219

PARAMETER: SULPHATE

RANGE: 5-100, 25-500 mg/l as SO₄**2 METHOD**

Classic chemical method.

3 APPLICATION

Drinking Water, Mineral Water, Well Water, Swimming Pool Water, Surface and Ground Water, Aquaculture, Boiler Water, Process Water, Industrial Wastewater, Effluent Water, Cooling System Water, Chiller Water etc

4 INTERFERENCE

None

5 METHOD CONTROL

To Check test reagents,

prepare 1000 ppm Sulphate standard:- Take 1.479 gm of anhydrous sodium Sulphate in 1000ml standard volumetric flask, Dilute It with Demineralised water up to 1000ml mark, stir well. Dilute this standard solution with distilled water to 100 mg/ISO₄L and 500 mg/l SO₄ and analyse as described in procedure card.**6 REAGENTS AND ACCESSORIES**

Reagents: NSP2(1Nos), NSP5(1Nos), NSP6(1 Nos)

Accessories: 10 ml Test Jar(1Nos), Procedure Label(1Nos), Syringe, Spoon

7 STORAGE

The test reagents are stable up to the date stated on the pack when stored closed at ambient temperature.

8 REFERENCE

Classic chemical method.

9 DIRECTION FOR USE

1. Take 2 ml sample in Test jar by using syringe (provided herewith)

2. Dilute with Alcohol (Isopropanol) (AR/GR) up to the 10 ml mark.

Mix well.

(Note: Since the Alcohol is inflammable in nature, it is not provided with the test kit)

3. Add one spoonful of NSP2. Mix well.

4. Now drop wise add NSP5 counting the number of drops while mixing until the yellow colour change to saffron red.

If the expected Sulphate content of the sample is more than 100 ppm, then use NSP 6 instead of NSP 5.

Calculations:

Sulphate as ppm SO₄ = 5 x (No. of drops of NSP 5)Sulphate as ppm SO₄ = 25 x (No. of drops of NSP 6)